



HOOKER
— FURNITURE —

ASSEMBLY INSTRUCTION

Item: 5382-75001/75002/75003





Round dining table

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:

HARDWARE PACK

NO	DRAWING	DESCRIPTION	SIDE	Q' TY
A		BOLT	Ø1/4" * 3/4"	4pcs
B		LOCK WASHER	Ø1/4"	4pcs
C		FLAT WASHER	Ø1/4" * 19mm	4pcs
D		ALLEN WRENCH	4mm	1pc



Step 1